

gizDuino miniUSB

How to install USBasp driver to PC? If you are using gizDuino miniUSB?

In order to use gizDuino USB mini, we need to install the USBasp driver. If there is no USBasp driver installed to your computer, a pop-up note will appear indicating "Found new hardware USBasp".

Download driver: <http://e-gizmo.net/oc/kits%20documents/GIZDUINO%20FOLDER/Drivers.zip>

1st Option:

1. Connect the gizDuino mini USB to PC.
2. Open Device Manager>Search the USBasp. (if there's a caution image- it means the driver is not installed properly or not detected.)
3. Right Click in USBasp>Update Drivers>Search automatically for updated driver software.
4. If nothing happens, select Browse my computer for driver software>locate the "usbasp-windriver.2011-05-28.", then wait until Driver installation successful. Done!

Unique solution ID: #1016

Author: Roma Mercado

Last update: 2018-04-18 10:55