

gizDuino miniUSB

Another USBasp driver installation (option 2) for gizDuino miniUSB. Using Zadig driver.

Download the Zadig at : <http://zadig.akeo.ie/>

Connect the gizDuino miniUSB to PC. Select: USBasp Driver: libusbK(v3.0.7.0) Click Install Driver.

Go to Device Manager> Search "libusbK USB Devices"> USBasp (If usbasp appear and no caution image - it is success!) You may now use the gizDuino miniUSB.

Unique solution ID: #1017

Author: Roma Mercado

Last update: 2018-04-18 11:01