SIM800L Shield

What happens if the replies of SIM800L shield is not exact characters? (ex. if i send "Hello", then i received like this "

Check your codes, if you are using SoftwareSerial Library and the assigned pins to RX (D2),TX (D3).
On the SIM800L shield there's a slide switch for serial select use SUART pin (2,3).

Unique solution ID: #1104
Author: Administrator
Last update: 2018-04-21 08:22