

4 Direction / Tilt Sensor

What is the Operating voltage of 4 Direction/ Tilt Sensor?

The Power input is 3.3 to 5VDC. You can use the power source from gizDuino / Arduino.

Unique solution ID: #1044

Author: Administrator

Last update: 2018-04-20 08:53