

ACS Current sensor (ACS-711T)

What is the Power input of ACS current breakout board?

Its 5VDC, You can use the power source from gizDuino/Arduino.

Unique solution ID: #1049

Author: Administrator

Last update: 2018-04-20 09:13