

Sensor Amplifier Kit

What is the Operating voltage of Sensor Amplifier kit?

Its 9~12VDC,use external power supply (adaptor) connect it to DC jack of Arduino/gizDuino then in power source VIN.

Unique solution ID: #1067

Author: Administrator

Last update: 2018-04-20 11:14