

Through Beam Sensor

What is the Operating voltage of Through Beam sensor?

Its 5VDC, you can use the power source from Arduino/gizDuino.

Unique solution ID: #1077

Author: Administrator

Last update: 2018-04-20 11:42