

# **Coinslot Single Coin**

## **What is the Operating voltage of Coinslot Single Coin?**

Its +12VDC, use external power supply (adaptor) or connect it to DC jack of Arduino/gizDuino then in power source VIN.

Unique solution ID: #1090

Author: Administrator

Last update: 2018-04-21 04:35