

# **SIM800 Development Board**

## **What is the Operating voltage of SIM800 Development Board?**

It needs +5V 2Amp power supply to work.

Bandspeed Adaptor with 5V 2.6A: [http://www.e-gizmo.net/oc/index.php?route=product/product&product\\_id=46621](http://www.e-gizmo.net/oc/index.php?route=product/product&product_id=46621)

Unique solution ID: #1092

Author: Administrator

Last update: 2018-04-21 04:48